


## SEFIS DB SERVICE Paddock STAND

### MANUAL



#### Use

- ◆ Place the motorcycle on a flat surface with a rough texture, such as a parking lot with asphalt, rough concrete, or concrete paving. Do not use the stand on a heavily dusty or muddy surface, sand, or a smooth surface such as smooth concrete, glazed paving, etc. It could slip.
- ◆ Remove the stand from the packaging and remove the strap with the velcro. Press the front brake lever of the motorcycle and fix it to the handlebar with the velcro strap to keep the motorcycle secured during lifting.
- ◆ Remove the screw with handle from the stand, spread the arms of the stand, and secure them with the screw in the spread position. Then, unscrew the lift leg to the required height and secure it with the locking nuts.



#### Introduction

- ◆ The service paddock stand is practical tool for easy lifting of the rear wheel of most motorcycles with a side stand. It is a great addition to motorcycles without a main stand for common maintenance tasks such as chain cleaning, tire inspection, and washing the rear wheel.



#### Use

- ◆ Place the stand under the swingarm on the right side of the motorcycle.



- ◆ Step on the foot of the stand with the tip of your shoe and smoothly press down the lever. This will lift the rear wheel. After finishing the work, raise the lever up again, remove the stand, and the velcro strap from the brake lever.

