

Skewer grill with USB electric spits

Instructions for use:

1. Fold out both legs of the grill and place it on a flat surface.
2. Flip up all 4 sides.
3. Pull out the plate holders on both sides and place the plates.
4. Place a bowl with fuel inside the grill and you can cover it with a grate (if a grate is needed according to the method of use). We recommend first making holes in the fuel bowl for better air flow.
5. It is possible to set 2 distances of the coals from the grate. The distance adjuster also serves as a basket holder.
6. When using a large spit - insert the holders on both sides of the grill into the pockets and place the spit on them with the sharp side in the motor socket.
7. Attach the motor from the outside of the grill according to the method of use (large spit - to the front / 4 small spits - to the back of the grill). Tighten the motor lock counter-clockwise.
8. Stick the sharp side of the skewers into the holes in the back wall of the grill.
9. Place the lower part of the spit (it has L-shaped holes with a wire in it) approx. 3 cm from the handle and tighten both screws evenly (wider insert of the screw towards the inside).
10. Place the top of the spit (it has round holes in it) just behind the tip of the spit and tighten both screws evenly (wider insert of the screw towards the inside).
11. Insert the needle through the hole L of part #9 so that the tip of the needle is inserted into the circular hole of part #10. It should come out so that the needle screw is at the same level as the L-shaped lock. You lock the needle in the lock by turning it to the right.
12. Connect the USB cable from the motor to the power bank or phone charger adapter.

